




High Valley 1300 Wiring Diagram



POWER CORD

Exits stove from Switch Bracket and connects to 120v AC current. Black is “hot”, White is “neutral”, and Green is “ground”.

RHEOSTAT (Part # RHESTA)

Located on Switch Bracket and turns variable fan speed from High to Low and clicks Off. Has two wires exiting back, with one wire taking power from Power Cord and other wire putting power into Fan Blower.

FAN BLOWER (Part # BLO1300)

Comes mounted on back of stove and has two wires exiting housing. One wire is coupled with White “neutral” from Power Cord while the other wire connects to the Rheostat for power. Both wires work with either connection.

BLOWER KIT (Pre-Installed)

Includes Fan Blower, Rheostat, Mounting Bracket and Power Cord.

Replacement parts are available at www.highvalleystoves.com

Technical support is available: (1) Call your local dealer, (2) Email sales@highvalleystoves.com, or (3) Call 800.421.0771.